


FM Radio

Model SCP-02

WARNING: Always check your wiring before turning on a circuit. Never leave a circuit unattended while the batteries are installed. Never connect additional batteries or any other power sources to your circuits.



WARNING: SHOCK HAZARD -
Never connect Snap Circuits to the electrical outlets in your home in any way!



Project #1

FM Radio

The Snap Circuits Kit uses electronic blocks that snap onto a clear plastic base grid to build different circuits. These blocks have different colors and numbers on them so that you can easily identify them. Build the circuit shown by placing all the parts with a black 1 next to them on the clear plastic base grid first. Then, assemble parts marked with a 2, then parts marked with a 3, and finally, parts marked with a 4. Install three (3) "AA" batteries (not included) into the battery holder (B3).

Turn on the slide switch (S1) and press the R button on the FM module (FM). Now press the T button and the FM module scans for a radio station. When a station is found, it locks on to it and you hear it on the speaker (SP). Adjust the volume using the adjustable resistor (RV). The resistor controls the amount of signal into the power amplifier (U4). Press the T button again for the next radio station. The module will scan up to 108MHz, the end of the FM band, and stop. You must then press the R button to reset at 88MHz again.

Project #2 Power Amplifier

Modify the circuit shown by removing the 2-snap wire and the single snap that are connected to the FM module (FM), note that the single snap is beneath the adjustable resistor (RV).

Position the adjustable resistor (RV) at the top and turn on the slide switch. You should be able to touch point A with your finger and hear static. Listen closely to the speaker (SP) or wet your finger if you don't hear any sound. High frequency clicks, static or even an AM radio station should be coming from speaker indicating that the amplifier is powered on and ready to amplify signals.

The power amplifier may oscillate on its own. Do not worry, this is normal with high-gain, high-powered amplifiers.

Project #3 Electronic Kazoo

Use the circuit from project 2. When you place one finger on point A and a finger from your other hand on the point B, what happens? If the amplifier starts to oscillate, it is due to the fact that you just provided a feedback path to make the amplifier into an oscillator. You may even be able to change the pitch of the oscillation by pressing harder on the snaps.

This is the principle used to make an electronic kazoo. If you practice and learn the amount of pressure required to make each note, you may even be able to play a few songs.

Project #4 Trombone

Use the circuit from project 3.

Turn on the slide switch (S1) and place one finger on point C and a finger from your other hand on point B. The trombone should start playing due to the fact that you just provided a feedback path to make the amplifier into an oscillator. To change the pitch of the sound, simply slide the adjustable resistor (RV) control back and forth. By moving the slider, you will be able to play a song much like a trombone player makes music. The RV control is the same as a trombone slider bar. The circuit may be silent at some positions of the resistor control.


If you have any problems, contact Elenco®

Copyright © 2005 Elenco® Electronics, Inc. All Rights Reserved. • 150 Carpenter Ave. • Wheeling, IL 60090
(800) 533-2441 Fax: (847) 520-0085 • e-mail: elenco@elenco.com • Web site: www.elenco.com or www.snapcircuits.net

753141
REV-A

OTHER SNAP CIRCUITS PRODUCTS!

Contact Elenco® to find out where you can purchase these products.



Snap Circuits Jr. Model SC-100

Build over 100 projects, contains over 30 parts.



Snap Circuits Model SC-300

Build over 300 projects, contains over 60 parts.




Snap Circuits Pro Model SC-500

Build over 500 projects, contains over 75 parts.



Snap Circuits Extreme Model SC-750


Build over 750 projects, contains over 80 parts, and PC interface included.




Musical Recorder Model SCP-01




Motion Detector Model SCP-03



Music Box Model SCP-04



Space Battle Model SCP-05



Flying Saucer Model SCP-06

PARTS LIST

Qty.	ID	Name	Part #
<input type="checkbox"/>	1	Base grid	6SCBGM
<input type="checkbox"/>	4	1	1-snap wire 6SC01
<input type="checkbox"/>	5	2	2-snap wire 6SC02
<input type="checkbox"/>	2	3	3-snap wire 6SC03
<input type="checkbox"/>	1	B3	Battery holder 6SCB3
<input type="checkbox"/>	1	FM	FM module 6SCFM
<input type="checkbox"/>	1	RV	Adjustable resistor 6SCRV
<input type="checkbox"/>	1	S1	Slide switch 6SCS1
<input type="checkbox"/>	1	SP	Speaker 6SCSP
<input type="checkbox"/>	1	U4	Power amp IC 6SCU4

Important: If any parts are missing or damaged, **DO NOT RETURN TO RETAILER.** Call toll-free (800) 533-2441 or e-mail us at: help@elenco.com.
Customer Service • 150 Carpenter Ave. • Wheeling, IL 60090 U.S.A.

You may order additional / replacement parts at our web site: www.snapcircuits.net

BATTERIES:

Use only 1.5V AA type (not included). Insert batteries with correct polarity. Non-rechargeable batteries should not be recharged. Rechargeable batteries should only be charged under adult supervision, and should not be recharged while in the product. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Remove batteries when they are used up. Do not short circuit the battery terminals. Never throw batteries in a fire or attempt to open its outer casing. Batteries are harmful if swallowed, so keep away from small children.